Swop Mop Sponge Mop

> User Guide


Autoclavable Sponge 800934 | 29.7cm 800929 | 33cm

Swop Mop Holder


800933 | 29.7cm

800928 | 33cm


Push hand lever to the full forward position. This brings the sponge holder into the correct position to accept the sponge.




Using the arrows located on the sponge for guidance, slide the sponge into position.



Bring the hand lever into hold position. This allows the rollers to secure the sponge in position.



Immediately submerge the sponge into water for 20 seconds. The expansion of the sponge will lock it in place during use. (Do not allow sponge to touch the bucket base during this time.)



To remove excess water, pull back the lever until the rollers move over the sponge, squeezing out all the water, then return to the hold position. (But not back to Step 1 as this allows the sponge to be released).

NEVER attempt to wring out when the sponge is dry as this will damage the wringing mechanism.

NEVER force a replacement sponge into holder, check the position (STEP 2.) of the arrow on the sponge.

ALWAYS store sponge wringers by hanging them on the handle hook.

